




1 Locating the IMEI no.

Locate the tracker's IMEI number and have it ready to enter into the 'GPSlive app' at step 3.
The tracker's IMEI number can be found on the sticker on the side of the tracker.



2 Sim Card Top-up

Visit www.giffgaff.com to top-up your SIM card. You will need to register your SIM prior to topping up. Follow the instructions on the giffgaff website. Do not choose any bundle, just click on 'Activate your SIM by topping up' button at the bottom of the top up page and choose £10 top up. The SIM should be topped-up at least every 180 days to remain active.




3 Smartphone APP

Download **GPSlive** app from either the Apple APP Store or Android Play-store.
Note: If you are already a GPSlive user please skip to step 4.




4 Registration

Open the GPSlive app and tap on the "Create new account" button. Fill in the fields and select "register". Your password will be sent to you via email.
Note: your email address will also be your user name when you log in.



5 Receiving Login Details

Check your inbox for an email from GPSLive, including your credentials. If you haven't received an email from us within 2 minutes, please check your spam / junk mail folder.



6 Adding your tracker

Log-in to the GPSLive app using your credentials, go to "Devices" and then "Add Device". Fill in the fields and save.
Note: Fill in the name field with a name of your choice for your GPS Tracker.



7 Antennas

Screw both GPS and GSM antennas into corresponding connectors on the side of the tracker. These will be clearly marked on the side of the tracker. GPS Signal penetrates through plastic, wood fabric, and glass; however, thick metal surfaces or concrete will reduce its strength. Try to find a suitable position for the tracker and antennas bearing the above in mind.



8 Powering Up/Connection

Connect your 103 PRO to your vehicle's power supply using the harness provided. We recommend that this installation is carried out by an auto electrician. You can find the wiring diagram on the reverse of this quick user guide. Turn the device on and it will automatically start uploading its location.



1 Registration


To register your tracker and activate your free 12 months GPSLive access, fill out the registration form from the link below;
www.rewiresecurity.co.uk/registration

Note: This should be done within 7 days after adding your tracker to your GPSLive account.



2 Antenna / Hardwiring

Use wiring loom to connect 103 PRO to your vehicle's power supply as per wiring diagram. 103 PRO has external antennas which need to be fitted to the tracker before it is operational. Ensure that the antennas are connected the right way round as per markings on the tracker. Red caps need to be removed prior to antennas being connected. Ensure they are screwed tightly but do not overtighten them.



3 Fitting the device

Device has to be connected to a permanent live feed of the vehicle. We recommend that installation is carried out by a professional auto electrician. Tracker's antennas need to be located in a position where they can receive sufficient signal for the tracker to operate smoothly. Ideal location would be under the dash board of your vehicle as GSM and GPS signals are able to penetrate plastic. We do not recommend installing the tracker under the bonnet as signals will not penetrate metal.



4 Status LED lights

Green: GPS signal. This LED will stay solid green once the device has picked up a GPS signal. If the LED is off, your device is still searching for a GPS signal.
Red: GSM/Mobile phone network status. If your LED is solid red, your device has no GSM network signal. Fast flashing red means that the tracker acquired GSM signal and slow flashing red indicates that it has successfully connected to the internet.

Q Why is my tracker not updating it's location?

- A**
- If this is the first time you are using your tracker, it may take a while to establish a GPS lock. .
 - Make sure the SIM card installed in the tracker has credits. You can check your balance by logging on to your account on; www.giffgaff.com.
 - Check if the tracker is powered up, switched "On" and LED lights of your tracker as per step number four.
 - Check that the IMEI number of the device matches the IMEI you have entered when you have registered the device on our tracking platform.

Q Green LED is off

- A** This mean GPS is searching for satellite signal. Try moving antenna to more suitable position. Ensure that antenna is screwed in tightly and check for any obstructions around the antenna.

Q Red LED is not flashing

- A** If the red LED light stays solid, this means there is no GSM/mobile network signal. Check that antenna is screwed in tightly and try to move it to more suitable location. Ensure that antennas are screwed into correct port. Once the device has established GPRS connection, frequency of flashing will be at a rate of about once per second. This indicates that the device is ready to update its location via the internet connection and you can use it to continuously update its location via our tracking platform.

Wiring Diagram

